


PREVENTATIVE PARTS														
<p>The PREVENTIVE parts inventory is particularly recommended for turbines in highly critical installations, remote locations and/or where back-up capacity is partial or nonexistent.</p> <p>When combined with the VITAL and IDEAL inventories they form a "long term spares inventory".</p>														
<p>This recommended Spare Parts List was prepared specifically for your unit.</p>														
TAG NUMBER		TYPE	Manufacturer's Part Number	TOTAL NUMBER OF IDENTICAL PARTS INSTALLED		SPIR LINE NO.	Units of Measure	DESCRIPTION OF PART	SECTIONAL DRAWING NUMBER (Attach to SPIR)	Part Position (Reference) No.	SELLER'S PART NUMBER	Quantity recommended	CUSTOMER CATALOG NO.	Shipment (working days)
TURBINE ROTOR ASSEMBLY														
1	1	EA	TURBINE ROTOR ASSEMBLY	OR28844	6R9051-1									
GOVERNOR LINKAGE ASSEMBLY														
1	1	EA	CLAMP BLOCK	OR28838	3	1A9622-1								30
1	1	EA	SPECIAL PIN	OR28838	4	1A5925-11								30
2	2	EA	DRAG LINK	OR28838	6	3A3330-132								50
2	2	EA	NEEDLE BEARING	OR28838	7	1A5605-7								30
2	2	EA	INNER RACE BEARING	OR28838	8	1A5606-1								30
3	3	EA	PIN	OR28838	9	1S394-134								30
10	10	EA	COTTERPIN	OR28838	10	1S447-3								30
2	2	EA	DRAG LINK	OR28838	17	3A3330-5								30
STEAM CHEST														
1	1	EA	VALVE SEAT UPPER	OR28837	8	3R2897-4								50
1	1	EA	VALVE SEAT LOWER	OR28837	9	3R2896-4								50
HANDVALVE														
2	2	EA	HAND VALVE GASKET	OR12786-5150	4	3A1948-146								30
SUB TOTAL PREVENTATIVE														